


Zumoji Y25 Mini Camera

User Manual



Camera Structure



Operation

► Photo Mode

Short press

▲: Switch to **Video Mode**

▼: Change **Filter**

Long press

▲: Turn **Sound On/Off**

▼: Turn **Flash On/Off**


► Video Mode


After power on, short press ▲: Enter **Video Mode**

Short press OK: **Start/Stop** recording

Press  again: Enter **Playback Mode**

► **Playback Mode**

After power on, double press : Enter **Playback Mode**


Long press  (3–5 sec): Return to **Photo Mode**

Long press : Enter **Menu Options**




Short press  : **Browse files** on memory card

► **Set Time:**

By connecting the PC

1. Insert memory card & connect the camera to PC
2. Select "Storage Mode" and press  button
3. Open PC folder, double-click update_time.bat to sync time
4. Unplug USB, turn camera off and on – time is updated

By entering the menu options

1. In the playback mode, long press : Enter **Menu Options**
2. Select "Time Settings" and press  button
3. Do the time settings in this page
4. Long press  (3–5 sec): Return to **Previous page**

Check the Y25 Operation Tutorial here:



If you need any further assistance, please email to sales@lookingtaiwan.com

THANK YOU!